

Instruction Manual

MODEL # ATC-20

20" Automatic On-Line Reeler

The Conair Group, Inc.

One Conair Drive
Pittsburgh, PA 15202
Phone: (412) 312-6000
Fax: (412) 312-6227



WARNING - Reliance on this Manual Could Result in Severe Bodily Injury or Death!

This manual is out-of-date and is provided only for its technical information, data and capacities. Portions of this manual detailing procedures or precautions in the operation, inspection, maintenance and repair of the product forming the subject matter of this manual may be inadequate, inaccurate, and/or incomplete and cannot be used, followed, or relied upon.

Contact Conair at info@conairgroup.com or 1-800-654-6661 for more current information, warnings, and materials about more recent product manuals containing warnings, information, precautions, and procedures that may be more adequate than those contained in this out-of-date manual.

UGE029/0597

Table of Contents

Section 1	GENERAL SPECIFICATIONS
Section 2	INTRODUCTION
2.0	General Description
Section 3	PRE-INSTALLATION INSTRUCTIONS
3.0	Facility Requirements
3.1	Skid Removal And Inspection
3.2	Preparation For Installation
Section 4	INSTALLATION INSTRUCTIONS
4.0	General
4.1	Physical
4.2	Power
4.3	Compressed Air
4.4	Peripheral Equipment
Section 5	START-UP AND CALIBRATION
5.1	General
5.1	Safety Precautions
5.2	Power Off Inspection
5.3	Power On Set-Up And Calibration
5.4	Core Diameter Set-Up
5.5	Blade Replacement
5.6	Operational Start-up
Section 6	DIAGNOSTICS
6.0	General
6.1	Electrical/Electronic System
6.2	Mechanical / Pneumatic System
6.3	Functional Diagnostics Index
6.4	Schematics Drawings - Electrical/Electronics
6.5	Manufacturer Specification - Electronic
6.6	Schematic Drawings - Pneumatic System
6.7	Manufacturer Specification - Pneumatics
6.8	Manufacturer Specification - Mechanical

Table of Contents

Section 7	PREVENTATIVE MAINTENANCE RECOMMENDATIONS
7.0	General
7.1	Mechanical
7.2	Pneumatic System
7.3	Electrical Components
Section 8	REPLACEMENT PARTS RECOMMENDATION
8.0	Spare Parts - Mechanical
8.1	Spare Parts - Pneumatic
8.2	Spare Parts - Electrical
8.3	Warranties and Exclusions
Section 9	DOCUMENTATION
9.0	B/M - Electrical / Electronic Components
9.1	B/M - Mechanical Components, R - L Model
9.2	B/M - Mechanical Components, L - R Model
9.3	B/M - Pneumatic Components
9.4	Drawings - Electrical/Electronic Assembly
9.5	Drawings - Mechanical Assembly
9.6	Drawings - Pneumatics Assembly

Index of Drawings and Figures

SECTION	DESCRIPTION	DRAWING No.
6.4	Schematic - Electrical/Electronic	DX559-877 SHEETS 1&2
6.6	Schematic - Pneumatic System	DX559-886 - 0814-091&2
9.4	ELECTRICAL/ELECTRONIC ASSEMBLY DRAWINGS	N/A
9.5	MECHANICAL ASSEMBLY DRAWINGS	
9.5.1	Upper Traverse Assembly	DX559-693 - 0814-06123
9.5.2	Product Guide Assembly	CX559-691 - 0814-06107
9.5.3	Pusher Assembly	CX559-683 - 0814-05992
9.5.4	Vertical Roller Assembly #1	CX559-642 - 0814-05429
9.5.5	Detector Assembly	BX559-664 - 0814-05739
9.5.6	Lower Traverse Assembly	RX559-796 - 0814-07766
9.5.7	ATC Coiler Drive Assembly	RX559-1112 -
9.5.8	7 1/4 Collapsible Spool Assembly	DX559-734 - 0814-06794
9.5.9	4 1/4 Collapsible Spool Assembly	DX559-750 - 0814-07162
9.5.10	VERTICAL ROLLER ASSEMBLY #2	CX559-647 - 0814-05496
9.5.11	Turret Assembly	RX559-823 - 0814-08231
9.5.12	Cutting Tool Assembly	DX559-633 - 0814-05283
9.5.13	Detent Assembly	DX559-872 - 0814-08908
9.5.14	Shot Pin Assembly	DX559-1114 - 0814-09106
9.5.15	Loop Sensor Pedestal Assembly	CX559-907 - 0814-09483
9.5.16	Lock Collar Ass'y	CX559-717 - 0814-06476
9.5.17	IDLER Ass'y	BX559-687 - 0814-06069

SECTION 1 GENERAL SPECIFICATIONS

1.0 - GENERAL

The Conair / Gatto On-Line Reeler has been developed for those applications where winding tension is required to be maintained at minimum levels. The two position Turret unit employs ultrasonic pulses to maintain a loop or sag in the product tubing as it is fed to the reeler. With the automatic cut and transfer feature, the unit will, upon receipt of a signal from the total length counter, index the full package to the unload position and then cut and transfer at the winding position. Cut, transfer, and start-up of the empty spindle occurs in approximately six seconds.

The Spindle Drive is a 2 h.p. DC-SCR regenerative system.

The Turret Drive is a 1/2 h.p. A.C. gear motor.

The Traverser is a precise cam action - variable pitch transmission. The pitch is adjustable over a wide range, wherein the minimum pitch is equal to the maximum pitch divided by 15. The maximum traverse is 12 inches. The traverser slows down proportionally with the spindle as the coil package builds up. Traverse motion is stopped for one complete coil revolution to ensure a complete wrap at the coil ends.

Loop detection is by Ultrasonic Position Detector making no contact with the product. The sensor determines the loop position by reflection of time sequenced ultrasonic tones.

The Product Guide System provides for precise lay-on with minimal tension.

The control and electrical system consist of start and stop push buttons, enable push button, rapid take-up speed push button, rapid take-up speed potentiometer, turret drive push button, reset push button, shift production display, line speed display, low air p.s.i. indicator, coil length counter, internal programmable controller, SCR and regenerative drive. Automatic cut and transfer feature is also included.

The product size range which may be coiled with the Conair / Gatto ATC-20 Reeler ranges from a minimum of .070 O.D. to a maximum of .500 O.D.. The coiling speed range is 70 to 500 linear F.F.M..

The spools available are 7 1/4" dia. collapsible to 6 3/4" and 4 1/4" collapsible to 3 3/4", continuous wrap or segmented ss core.

SECTION 2 INTRODUCTION

2.0 - GENERAL

This manual familiarizes the user with the Conair / Gatto ATC-20 Reeler. It describes assembly and installation procedures, gives a general overview of operation, and contains information on diagnostics, installation, maintenance, spare parts recommendation, and manufacturers' specification.

This manual should be read before performing installation or start-up activities. There are also certain fundamental warnings and precautions which must be kept in mind at all times. These are :

CAUTION

DISCONNECT ALL ELECTRICAL POWER TO THIS MACHINE AT THE POWER SOURCE AND ENSURE THAT ALL MOTION HAS STOPPED BEFORE OPENING OR REMOVING OPENING CONTROL BOX OR REMOVING PANELS, DOORS OR GUARDS !!!

DANGER

ELECTRICAL AND ELECTRONIC CONTROLLER EQUIPMENT IS AT LINE VOLTAGE WHEN A.C. POWER IS CONNECTED. THEREFORE, A.C. POWER MUST BE DISCONNECTED BEFORE IT IS SAFE TO TOUCH INTERNAL COMPONENTS OF THIS EQUIPMENT. PERSONAL INJURY MAY RESULT UNLESS POWER IS REMOVED.

SECTION 3 PRE-INSTALLATION INSTRUCTIONS

3.0 FACILITY REQUIREMENTS

Electrical : 230 V.A.C./1 Phase/60 Hz/@ 1.8 K.V.A.

Air Supply : A dedicated, oil free, compressed air air line is required of 1/2 inch diameter or larger. The supply pressure should be a minimum of 80 P.S.I..

3.1 SKID REMOVAL AND INSPECTION

Upon receiving unit, inspect for any damage that may have occurred during shipping.

Remove skid from under machine frame.

Unlock castors prior to moving the machine.

3.2 PREPARATION FOR INSTALLATION

Map the intended installation area, allowing for operator and servicing access to front and rear panels. (See assembly drawing for strategic positioning of peripheral equipment and coiler with respect to product line)

Install proper electrical (3) wire female Twist-Lock Connector 230 V @ 30 Amperes.

Install flexible compressed air line hose of minimum 3/8" inside diameter and matching quick-disconnect to fitting supplied with machine.

SECTION 4 INSTALLATION INSTRUCTIONS

4.0 GENERAL

This section outlines the procedures that are to be followed in order to properly install the ATC-20 On Line Reeler.

There are certain general warnings and cautions that should be kept in mind before continuing with the installation. They are :

DANGER !!!

THIS MACHINE SHOULD BE INSTALLED, ADJUSTED AND SERVICED BY QUALIFIED TECHNICAL PERSONNEL, FAMILIAR WITH THE CONSTRUCTION AND OPERATION THIS TYPE OF EQUIPMENT. THEY SHOULD ALSO BE FAMILIAR WITH THE POTENTIAL HAZARDS INVOLVED IF THIS WARNING IS NOT OBSERVED. PERSONAL INJURY OR EQUIPMENT DAMAGE MAY RESULT.

DANGER !!!

BE ABSOLUTELY CERTAIN THAT A GROUND WIRE FROM THE INCOMING A.C. POWER LINE IS PROPERLY CONNECTED TO THE CHASSIS GROUND TERMINALS PROVIDED. WITHOUT PROPER GROUNDING, PERSONAL INJURY MAY OCCUR.

WARNING !!!

THIS EQUIPMENT REQUIRES A SINGLE PHASE POWER SUPPLY THAT PROVIDES 230 V.A.C.. IF CORRECT SUPPLY IS NOT AVAILABLE, IT WILL BE NECESSARY TO INSTALL A TRANSFORMER BETWEEN THE POWER SUPPLY AND THE MACHINE. DO NOT OPERATE EQUIPMENT AT POWER OTHER THAN THAT SPECIFIED, DAMAGE TO EQUIPMENT AND PERSONAL INJURY MAY OCCUR.

4.1 PHYSICAL INSTALLATION

Transport equipment to designated area and securely locate to floor utilizing (2) previously installed floor sleeves. Adjust level pad and pin lift screws as required to obtain desired height and proper leveling.

4.2 POWER WIRING

Single phase power to this machine is supplied through a three wire power cord terminating with a single phase three prong, 30 ampere NEMA Twist-Lock plug. Inter-connection to users power supply should be through a fused disconnect switch, in accordance with the National Electric Code and any applicable state and local codes. Final connection to machine should be through a matching female Twist-Lock type receptacle or connector.

4.3 COMPRESSED AIR

Connect previously installed air line (hose and and female quick disconnect) to matching connector located at air inlet port of machine.

4.4 PERIPHERAL EQUIPMENT

An ultrasonic positioning detector has been supplied in conjunction with the ATC-20 reeler. This unit should be placed equidistant from the reeler and the puller. The product flow line should be positioned in the center of the sensor guide bars when viewed from the top. The product height should be the same at the entrance and exit sides of the guide bars.

Connect the signal cable of the positioning detector to the (7) pin female Amphenol connector located at the bottom panel of the control box.


DISCONNECT POWER WHEN MAKING ABOVE CONNECTIONS !

SECTION 4 INSTALLATION INSTRUCTIONS

4.4 PERIPHERAL EQUIPMENT

Connect the supplied external encoder and cable to the mating (4) pin female Switch Craft connector, located at the bottom panel of the control box. Install the encoder onto processing equipment as required to obtain an accurate measurement of product travel.

Although it is not always recommended, because of the possibility of signal noise contamination, the coiler has the capability to share a signal generated from a compatible existing encoder in use with other equipment. However, a diode isolation circuit must be installed between the coiler signal input and the other system. Additionally, the encoder must generate 120 pulses per revolution, and the signal voltage or Encoder Output must be source or sink. Please refer to the integration diagram below for proper connection.



DIODE ISOLATOR
p/n 1N4148

DISCONNECT POWER WHEN MAKING ABOVE CONNECTIONS !

SECTION 5 SET-UP AND CALIBRATION

5.0 GENERAL

This section provides start-up and adjustment procedures to be followed after the assembly and installation of equipment is complete.

5.1 SAFETY PRECAUTIONS

- 1) NEVER OPERATE COILER WITH GUARDS OFF
- 2) DISCONNECT ELECTRICAL POWER AND AIR SUPPLY BEFORE REMOVING GUARDS OR ATTEMPTING TO SERVICE MACHINE
- 3) KEEPS HANDS AND FINGERS OUT OF THE TURRET AREA DURING OPERATION OF MACHINE.
- 4) ENSURE PROPER GROUNDING OF MACHINE FRAME.
- 5) ALL SERVICE TO THIS MACHINE IS TO BE PERFORMED BY QUALIFIED TECHNICAL PERSONNEL ONLY.
- 6) KEEP HANDS AND FINGERS AWAY FROM CUTTER HEAD.
- 7) DO NOT EXTEND CUTTER UNLESS SPINDLE IS COMPLETELY STOPPED.
- 8) DO NOT OPERATE MACHINE WITH SPOOLS' FLANGE UNATTACHED OR UNLOCKED.

5.2 POWER OFF INSPECTION

With all power disconnected, physically inspect all electrical components for proper tightness of connections, pin alignment, grounding and etc. Also inspect all mechanical components and tighten as may be necessary where any component may have become loosened during shipment.

- 6) The Ultrasonic Positioning Detector provided with this machine is set up at the factory and does not require adjustment. Refer to sect. 4.4 for proper positioning of product from puller through gage and to coiler.
- 8) The cutter extension location is fixed and should not require adjustment. To test operation and to confirm position, depress the " Power Enable " push-button (blue light will go out), then depress the extend cutter push-button located on the turret above the spool. Hand rotate the spool until detent is engaged. The cutter will automatically extend to position.

5.4 CORE DIAMETER SET-UP

The "Diameter control" potentiometer, is located in an equipment box to the rear of the entrance end of the machine. The dial is directly calibrated in inches. To set a empty core diameter of 7 inches set the dial to 7 or to desired value.

5.5 BLADE REPLACEMENT

- 1) Servicing of the blade is done in the wind position with the cutter extended.
- 2) DISCONNECT THE AIR SUPPLY FROM THE MACHINE !
- 3) Extend cutter head manually (see section 5.5 item #8)
- 4) Remove blade cover.
- 5) Loosen set-screw located at the side of the cutter cutter head
- 6) Remove the old blade.
- 7) Insert the new blade into slot until it bottoms.
- 8) Tighten set-screw, Note : do not over-tighten as blade may be damaged.
- 9) Replace the blade cover.

5.3 POWER ON SET-UP AND ADJUSTMENT

- 1) Power machine by turning the main disconnect to the on position.
- 2) No adjustment of the ultrasonic positioning sensor is required other than the proper physical positioning as discussed in section 4.4. Note, with no product in the gauge, or if the product is less than 2 inches from the floor, the red l.e.d. on the sensor head will strobe. As the product moves up toward the sensor the led will stop flashing.
- 3) Transverser reversing stop position is adjusted by turning of the corresponding right and left stop positioning knobs. Adjust should be made so that the center of the guide shoe on the transverser travels to the sides of the spool, but clearing the flanges to the desired product position.
- 4) The lay-on arm should be adjusted so that it rides about 1/16 inch above the empty reel core. To adjust the height of the lay-on arm, loosen the setscrew in the "clamp collar" assembly (draw CX559-683) and place the clamp so the arm is at the correct height. To adjust the height of the arm in the raised position the blue light on the operator control panel must be lit. This indicates that there is no air pressure supplied to the machine. If the blue light is not lit, depress the "All Stop" push button. Push the "pusher assembly", item 10, (Draw DX559-693) forward until the arm is in its upper most position. In this position the arm must clear the fully wound coil. To set the position, loosen the set screw in the block, item 5, and adjust screw, item 7. Re-tighten the set screw when adjustment is completed.
- 5) Adjustment of the lead pitch of the traverser should be made during start-up to suite the size of the product being coiled. (Refer to section 5.5 for specific instructions)

5.6 OPERATIONAL START-UP

BEFORE ATTEMPTING TO START MACHINE, REVIEW ALL SAFETY WARNINGS AND PRECAUTIONS LOCATED IN SECTION 5.1 OF THIS MANUAL !

- 1) Review section 4 to ensure proper connection of facilities, and peripheral equipment. Review all adjustments made for proper operation.
- 2) Ensure that empty reels are in place and locked to spindles.
- 3) Power unit by turning main disconnect to the on position.
- 4) Depress the " Machine Enable " push-button (The blue light should go out, indicating sufficient air pressure is available to operate the machine)
- 5) Reset the " Footage/Shift " counter by depressing the "reset" touch pad.
- 6) Set the " Footage/Reel " counter using the following procedure:

Depress the "arrow down" touch pad twice observe pst #2 to left of the digits.

Depress the "arrow right" touch pad.
The first digit will be high-lighted. To increase the value of the first digit depress the "Inc" touch pad. To reduce the value of the first digit depress the "Dec" touch pad.
To shift to the next digit depress the right arrow touch pad.
Use the above procedure to set the total product length required per reel.
Upon completion, depress the "arrow down" touch pad.

- 7) Obtain free end of product tubing from puller. Feed tubing through the Ultrasonic Positioning Unit. Guide end of tubing between the flanges of the lead spool and onto the cutter arm trap jaw.

WARNING KEEP HANDS AND FINGERS CLEAR OF ROTATING AND
AND CUTTING MACHINE COMPONENTS

- 8) Depress start push-button.
- 9) Depress quick pick-up push-button and hold while guiding tubing manually so that it remains parallel to the ultrasonic gauge head. Should the rate of pick-up be inadequate increase the quick pick-up speed control as necessary. When the tubing slack has been reeled so that its level forms a loop at the lower range of the Ultrasonic Positioning Detector, release the quick-pick up push-button.
- 10) Once the reeling rate is constant, back feed the product tubing through the Lay On Arm Guide, Guide Pulley and Vertical Guide Rollers.

SHOULD TANGLING OCCUR DURING ANY OF THE ABOVE
PROCEDURES IMMEDIATELY DEPRESS THE EMERGENCY STOP
PUSH-BUTTON

If the Emergency Stop push-button is depressed, it will be necessary to depress the "machine Enable" push-button before the run push-button has any effect.

If the machine is stopped because of a "tangle", (Tangle light is lit), the reset Push-button will have to be depressed before the start push-button has any effect.

If the machine is stopped because of "Loss length pulses", (Loss length pulses light is lit) the reset push-button will have to be depressed before the start push-button has any effect.

- 11) Once controlled reeling is active, the pitch of the traverser may be changed by adjustment to the indicator dial of the Graham Transmission. Rotate the indicator dial in a counterclockwise direction to increase the distance between each wrap of product. Inversely rotate the indicator dial in a clockwise direction to decrease the product wrap distance.

- 13) When adjustments are satisfactory in holding the coil loop constant and the desirable wrap distance has been obtained, then, depress the cutter extend push button, located above the lag spool. Next, depress the turret rotate push button. The machine will automatically cut the product tubing, transfer, and begin reeling a new spool.
- 14) Remove the lag spool flange and discard the unwanted product roll. Replace the flange and depress cutter extend push button located above the lag spool. Rotate the spool by hand until engaged. This completes initiation for the next automatic cycle.
- 15) Once the automatic sequence of operation is in effect, crossover from the full to empty spool is dependent upon the operator to remove the full spool from the lag spindle following each cycle, replace it with an empty spool, and depressing the cutter extend push-button, upon completion of the exchange. Failure to perform these operations will result in automatic shut-down following reeling of the lead spool.

SECTION 6 DIAGNOSTICS

6.0 GENERAL

This section details diagnostic information for the ATC-20 Automatic Reeler. Its organization is as follows:

- * General diagnostic concepts and referral to corresponding sections.
- * Specific cause and remedy procedures
- * Schematic drawings and manufacturer instructions, specification and diagnostic information where applicable.

6.1 ELECTRICAL/ELECTRONIC SYSTEM

Should it become necessary to diagnose an electrical or electronic wiring, control, component or inter-connection related problem; Please refer to the electrical schematic drawing located in section 6.4 and the manufacturers instructions and specification for electrical/electronic components located in section 6.5.

6.2 MECHANICAL/PNEUMATIC SYSTEM

For information detailing mechanical system or component specification; Please refer to the mechanical assembly drawings in section 9.4 and the manufacturers' specifications located in section 6.8.

For information detailing the pneumatic system; Please refer to the pneumatic system schematic drawing in section 6.6 and the manufacturers' specifications located in section 6.7.

6.3 FUNCTIONAL DIAGNOSTICS INDEX

PROBLEM DESCRIPTION	PROBABLE CAUSE	REMEDY
No response after depression of Machine Enable Push-button	Failure to connect or improper connection of Power Supply Main Disconnect OFF	Confirm proper connection. Confirm Power Supply is on. Turn to ON
Blue Air Pressure Indicator fails to extinguish after the Machine Enable is active.	Insufficient or no Air Supply to the Machine. Pressure Sensor is defective, or adjusted improperly. Failure of Main Air Solenoid.	Confirm that Compressed Air Supply is active. Adjust regulator 40 - 60 P.S.I. Check or adjust Sensor Replace Solenoid
Tachometer fails to display Reel speed.	If "Ft Coil" and "Total Ft" Counters are OK Tachometer failure	Check Diode (34) in Tach. Circuit Replace Tach.
Ft.Coil and/or Total Ft. Counters do not function	If Tachometer is functioning then Diode Failed	Check Diode (34) in the Counter Circuit
Ft. Coil Counter fails to start Turret rotation	If Turret rotates when the Push-button is depressed then "Ft/REEL" Counter has failed Failure of Micro-Processor Input Module	Failure of Relay Interface Board (36) Replace Counter Replace Input Module.
Machine keeps stopping and "Loss of Ft. Pulses" Indicator is lighted	Machine is being run at less 50 Ft./Min.	Set Low Speed Alarm on Tach to a lower set-point, refer to Dynapar Manual.

6.3 FUNCTIONAL DIAGNOSTICS INDEX

PROBLEM DESCRIPTION	PROBABLE CAUSE	* REMEDY
Coiler does not run following depression of Run Push-button but Enable is active	Fuller not running	Start Puller.
	Defective electronic related component F/V Converter Mechanical Drive component failure	Refer to section 6.4, 6.5, 6.3 replace if req'd Inspect Belt, Gearbox, etc.
Coiler stops running and Loss of FT. Pulse Light is on	Failure of Line Speed Proximity Sensor	Adjust- gap between sensor and screw Replace Sensor
Coiler speed too fast (product taught) or too slow (product slack)	Wrong Core Diam. selection	Correct Core Diam. setting
	Encoder incorrect or malfunctioning	Replace Encoder
	Drive Controller is malfunctioning	Repair or repl. Drive Control. Refer to section 6.5
	PID Loop is out of calibration	Calibrate PID Loop. See section 6.3 - PID Loop Calibration
	PID Control System component defective	Locate, replace defective components. Refer to section 6.3, 6.4, 6.5
	Ultrasonic Position Unit malfunction	Check for proper inter-connection Replace Sensor
	Run/Test Switch is not in the "run" position.	Place switch in "run" position

6.3 FUNCTIONAL DIAGNOSTICS INDEX

PROBLEM DESCRIPTION	PROBABLE CAUSE	* REMEDY
Depression of Quick-Pick-up Push-button fails to increase the reeling speed	Quick Pick-up Push-button failure Circuit failure Quick Pick-up Speed Pot. incorrectly set	Replace Push-button Switch Test Circuit, refer to section 6.4 Re-set to an appropriate value
Machine fails to stop when Stop Push-button depressed	Push-button failure Program Cont. Output Module failure	Replace P.B. Replace output module.
Machine fails to stop when "All STOP" P.B. is depressed.	P.B. failure Relay failure	Replace P.B. Replace Relay 1 CR, refer to section 6.4
Turret fails to rotate when Rotate Turret Push-button depressed	Operate failed to "Extend Cutter" Push-button Switch failure Turret Motor failure Turret Overload Mechanical Turret Drive component failed	Extend Cutter refer to section 5.6. Replace Push-button Switch Replace Turret Motor Test Overload Test Motor Refer to section 6.4,6.5 Test Turret Drive parts for binding Test Clutch for slippage
	Shot Pin failed to retract	Test Pneumatic Solenoid, Cyl. Refer to section 6.6

6.3 FUNCTIONAL DIAGNOSTICS INDEX

PROBLEM DESCRIPTION	PROBABLE CAUSE	* REMEDY
Turret keeps turning	Failure of "Turret IN POS" limit switch #44 DX559-877	Replace Limit switch.
	Low Air Pressure	Raise Air PSI
Traverse fails to operate when drive is active	Drive Chain or Belt failure	Replace, refer to section 9.5, 9.1
	Reel Speed Proximity Proximity Switch (50) DX559-877	Adjust gap between Sw. and disk if req'd Replace Sw.
	Traverse Solenoid failure	Repl. Solenoid
	Traverse to Start Proximity Sensor Failure	Check flag to sensor gap Repl. Sensor
Traverse speed too fast or slow	Traverse From End Proximity Sensor Failure	Check flag to sensor gap Repl. Sensor
	Incorrect speed ratio	Re-adjust Graham Transmission Refer to section 5.6, 6.8
Traverse fails to hold correct start position	Traverse From Start Prox. Sw. requires re-positioning	Adjust Prox.Sw.
	Poor or incorrect connection to above Sw. or circuit	Refer to section 6.4
	Traverse From Start Prox. Sw. defective	Replace, refer to section 9.0

6.3 FUNCTIONAL DIAGNOSTICS INDEX

PROBLEM DESCRIPTION	PROBABLE CAUSE	* REMEDY
Traverse fails to hold correct end position	Traverse From End Prox. Sw. requires re-positioning	Adjust Prox. Sw.
	Poor or incorrect connection to above sw. or circuit	Refer to section 6.4
Quick Traverse fails to operate when Turret is rotated	Traverse From End Prox. Sw. defective	Replace, refer to section 9.0
	Check output of Micro-Processor term. (13) wire #61 for 115v	Replace output module of Micro Processor, refer to section 6.5
Lay-on Arm fails to lift	"NEXT HOME" or "Cutter Home" Optical Sw. or reflector out of adj.	Adjust as needed
	Quick Traverse Solenoid failure	Replace solenoid Refer to section 9.3, 9.6
	Check output of Micro Processor term (16) wire# 64 for 115v	Replace output module of Micro Processor, refer to section 6.5
Lay-on Arm Fails to lower	Lift lay-on arm solenoid failure	Replace solenoid
	Improper flow setting	Re-adjust flow Refer to section 9.3, 9.6
Lay-on Arm Fails to lower	Mechanical component binding	Check Lay-on Arm mechanical parts
	115v continuously supplied to solenoid	Microprocessor OUT Module fail Replace module, refer to section 6.5, 6.4
Lay-on Arm Fails to lower	Adjustment of Cylinder Stroke Stop Block is incorrect.	Adjust Stop Block
	Improper flow setting	Re-adjust flow Refer to section 9.3, 9.6

6.3 FUNCTIONAL DIAGNOSTICS INDEX

PROBLEM DESCRIPTION	PROBABLE CAUSE	* REMEDY
Lay-on Arm lifts and/or lowers to the incorrect position	Lay-on Arm Cylinder Stop Block adjusted incorrectly	Re-adjust Stop Block, refer to section 9.5,
Cutter fails to extend	Faulty pneumatic part	Test pneumatic valves, solenoids Refer to section 6.6
Cutter fails to retract	"Cutter Home" Optical Sensor or Reflector incorrectly adjusted defective	Re-adjust Replace Sensor Refer to section 6.4, 6.5
Cutter extends or retracts to improper position	Mechanical component binding	Check Cutter mechanical parts Refer to section 9.5
Machine fails to stop during product tangle	Mercury Switch adjusted improperly Circuit failure Mercury Switch failure Microprocessor input module failure.	Re-adjust Check electrical Replace Mercury Switch (43) Replace Input Module Refer to section 6.5, 6.6
When tubing is taught Alarm fails to sound.	Wrong spacing between Taught Tube Prox. Sensor and Flag Microprocessor Input Module failure	Adjust gap Replace Module
Alarm fails to re-set when Re-set button depressed	Push-button Switch failure Microprocessor Input Module failure	Replace push-button SW. Replace Input Module

6.3 FUNCTIONAL DIAGNOSTICS INDEX - POSITION LOOP CALIBRATION

Please note that the PID Loop Control System has been calibrated and tested at the factory. Under normal circumstances calibration of this control should not be necessary. However, in the unlikely event that such calibration is required the following instructions will allow such adjustment, without the actual flow of product.

6.3.1 SONA-TROL SET-UP

REF.DRAW.DX559-1071

1. Apply power to the machine and depress the "Enable" push-button.
2. Tie a length of tubing diagonally between the vertical bars of the Ultrasonic Measuring Stand. The tubing should be placed approximately 3 inches from the base of the stand.
3. The Position Control System is located in a box to the rear at the entrance end of the machine. Loosen the latch screws, and swing the door to expose the Position Control Assembly.
4. The Sonatrol Assembly (item 2), is the pc board, located in the center of the panel #5. Note the "Time Filter" Indicators, located in the lower right hand corner of the board. These indicators should be strobing at this time. This strobing effect indicates that the gauge no longer senses the tubing. The Time Filter has been adjusted at the factory to indicate a tube loss, when the tubing is 3 inches, or less, from the base of the stand.
6. If the "Time Filter Indicators" are not strobing, adjust P5 on the Sonatrol Board until the lamps begin to strobe.
7. Shift the tubing in the gauge up, approximately, 1 inch from the position it is now in. The strobing should stop, with only the first indicator, to the left, remaining on.
8. Place the tubing 25 inches from the base of the gauge. Connect an oscilloscope to test point "POS", the common of the scope is connected to "com".
9. Place the "Run/Test" switch (item 14) to the Run position.
10. Adjust P1 on the Sonatrol Board for zero volts. This adjustment sets the tube position into the Control System. Tubing will maintain when the machine is running.

(Less than 10 mvolts is OK!)

6.3 FUNCTIONAL DIAGNOSTICS INDEX - POSITION LOOP CALIBRATION

11. Place the tubing 26 inches from the base of the gauge. Adjust P2 on the Sonatrol Board for +100Mv.

GAIN ADJUSTMENT OF THE PID SYSTEM (Ref. Draw DX559-1071)

1. To adjust the PID system for gain, the Sonatrol Ultrasonic Detector must be set up, as above, to yield a 100Mv signal when the tubing is 26 inches from the base of the gauge stand.
2. Place the "Run/Test" Switch (item 14) in the Run position. Connect an oscilloscope to the PID test terminal. The common terminal lead of the scope is connected to the COM test terminal. Adjust the LAG control on the PID Assy. (item 7), completely CCW. Place the "PID Enable/Disable" Switch to the "Disable" position. Depress the Drive Start push-button. The Reel will begin to turn very slowly. If the Puller is running, the Reel will turn at a speed determined by the puller Speed. Place the "PID Enable/Disable" Switch in the "Enable" position. Adjust the "Gain" Control on the PID Assembly so that the scope indicates a 5volt signal, each time the PID Switch is moved from the Disable to Enable position.
You will notice that the Reel will stop turning periodically. This is due to the automatic stopping of the machine when the computer senses loss of "Length" pulses. When the Reel stops, due to the loss of length pulses, depress the Start push-button and continue the test.

LAG ADJUSTMENT OF THE PID CONTROL SYSTEM (Ref draw.DX559-1071)

- 1) Check that the "LAG BREAK" Control on the PID Assembly is in the fully CCW position.
- 2) Place the "RUN/TEST" Switch in the "DC TEST" position.
- 3) Connect an oscilloscope lead to the "PID TEST TERMINAL". The common lead of the scope is connected to the "COM" test point.
- 4) Start the Reel Drive System by depressing the Start Push-button.
- 5) Place the "PID ENABLE/DISABLE" in the "ENABLE" position.

6.3 FUNCTIONAL DIAGNOSTICS INDEX - POSITION LOOP CALIBRATION

- 6) Adjust the "LAG" Control on the PID Assembly so that the signal at the test point "PID integrates to 10 volts in 10 sec. each time the "PID Enable/Disable" Switch is shifted from the "Disable" to "Enable" position. You will notice that the reel will stop turning periodically. This is due to the automatic stopping of the machine when the computer senses loss of "Length" pulses. When the Reel stops, due to the loss of "Length" pulses, depress the Start Push-button and continue test.

LEAD ADJUSTMENT OF THE PID CONTROL SYSTEM (Ref Draw. DX559-1071)

- 1) The PID Gain adjustment must be made before the Lead Gain is set.
- 2) Check that the "Lead Break" Control on the PID Assembly is set fully CCW.
- 3) Connect the scope test lead to the "POS" test terminal. The common lead of the scope is connected to the "COM" test point. Place the "RUN/TEST" Switch to the "AC Test" position. Measure and record the 60hz set-up signal observed. The signal will measure approximately 2.4 volts Peak to Peak.
- 4) Shift the scope lead to the "PID" Test Point. Place the "PID Enable/Disable" Switch to the "Enable" position. Depress the Drive Start push-button. Adjust the "LEAD" Control so that the signal at the "PID" test terminal is 1.5 times the signal at the "POS" terminal.

ADJUSTMENT OF THE FREQUENCY TO VOLTAGE CONVERTER (Ref. Draw. DX559-1071)

- 1) Apply power to the Coiler, depress the "Enable" push-button.
- 2) Apply power to the Puller. Set the Speed Control to zero.
- 3) Connect the test lead of an oscilloscope to test terminal "E/V". The common terminal of the scope is connected to the "COM" terminal.

6.3 FUNCTIONAL DIAGNOSTICS INDEX - POSITION LOOP CALIBRATION

LEAD ADJUSTMENT OF THE PID CONTROL SYSTEM (Ref. Dwg. #DX559-1071)

4. Adjust the P1 Trim Potentiometer on the F/V Assembly (item 4) for zero volts.
5. Increase the puller speed to 500 ft./min. Adjust the P2 Trim Potentiometer until the voltage at the F/V test point equals 10 volts.
6. Stop the puller, re-adjust the P2 Potentiometer for zero volts.
7. Run the puller at 500 ft./min. and if necessary, re-adjust P1.

REEL SPEED TEST OR SET-UP (Ref. Dwg. #DX559-1071)

The diameter control (Item 10) is set at the factory to provide the correct reel speed for the diameter of the reels ordered with the coiler. To test the reel speed control system for the original reels, or if new reels of a different diameter are used, the following procedure is required:

1. Run the puller at the required line speed.
2. Set the "diameter control" to the diameter of the reels used.
3. Place the "PID Disable/Enable" switch to the "Disable" position.
4. Start the coiler.
5. Measure the reel speed.

The reels should run at a speed determined by the following equation.

$$\frac{(\text{Line Speed Ft./Min.}) (12)}{(\quad) (\text{Dia. of reel core})}$$

For example: Line Speed - 400 Ft./Min.
Core Dia. - 4.5"

$$\frac{(400) (12)}{(3.14) (4.5)} = 339.7 \text{ RPM}$$

The reel speed should be set to run 10% faster than the required speed, therefore:

$$339.7 + 10\% = 374 \text{ RPM}$$

If the reel runs faster than the required speed, adjust the "MAX" Pot (Item 13) CCW.

If the reel runs slower than the required speed, adjust the "MIN" Pot (Item 12) in a CW direction.

6.3 FUNCTIONAL DIAGNOSTICS INDEX - POSITION LOOP CALIBRATION

TESTING THE FREQUENCY DIAMETER MULTIPLIER

The "FXD" Multiplier Assembly (item 5) receives two input signals. The first input is a dc voltage which indicates the speed of the Puller. This (0 to 10 volt) signal appears on terminal F/V. The second signal is derived from the setting of the "Coil Core Diameter" Potentiometer. The level of the diameter signal is 3 to 15 volts. This signal appears on the "DIA" test point.

1. To test the "FXD" Assembly, measure and record the voltage on terminal "F/V" (puller running at 250 ft./min), voltage should measure 5 volts.
2. Set the "Coil Core Diameter" Control to 5 (5inches). The voltage on test terminal "DIA", should measure 6 volts. The signal on the "FXD" test terminal should be equal to : $F \times D / 10$, or 3 volts.

TESTING THE SUMMING ASSEMBLY

The Summing Assembly (item 3) is supplied with two inputs. The first input is the signal from the "FXD" assembly. The second input is the signal generated by the PID Assembly. The two signals are algebraically summed together to provide the drive signal, appearing on the Test Terminal marked "DRIVE". The gain of the "Summing" Circuit is one.

1. Place the "RUN/TEST" Switch (item 14) in the " TEST DC" position. Run the Puller at 250 ft./min.
2. Start the Coiler by depressing the "Run" push-button.
3. Connect an oscilloscope lead to the test terminal marked "DRIVE". Place the "PID ENABLE/DISABLE" Switch in the Enable position. The signal at the "DRIVE" test point will start at some level and slowly decrease, until it reaches a level where the Coiler will stop turning.
4. Return the switch to the "PID DISABLE" position. Wait a few seconds then place the switch to the "DISABLE" position. The process of starting initially at a high speed and slowly decreasing will be repeated. The gain of the "Summing" Assembly is one.

(X) LAG GAIN DAN LEAD LEAD LAG
 BRK POS BRK

(7)

1	2	3	4	5	6	7	8	9	10
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(2) PI P2

 ZERO GAIN

SONATROL

TIME FILTER ADJUST
 P5

TIME FILTER
 ○○○○○○○

(3) PS-2

(4) F/V P2

(5) 11.5V 2

(6) 50V 3

GAIN
 OFFSET

PID
 DISABLE

(9) ENABLE

COIL CORE DIAMETER

(10)

(11)

MIN (12) MAX (13)

AC	DC
RUN	TEST TEST

(14)

F/V DIA FXD

POS PID DRIVE

COM

6.4 SCHEMATIC DRAWINGS - ELECTRICAL/ELECTRONICS

Part# 0814-30064
DX559-877
(SHEETS 1 & 2)

CONAIR

MACHINERY DEVELOPMENT

SECTION 8 REPLACEMENT PARTS RECOMMENDATION

- * L/R - The part indicated may be used with either a left or right configuration Model ATC-20 On Line Reeler.
- * L-R - The part indicated may be used only with a left to right configuration Model ATC-20 On Line Reeler.
- * R-L - The part indicated may be used only with a right to left configuration Model ATC-20 On Line Reeler.

8.0 SPARE PARTS MECHANICAL

<u>MACHINE</u> <u>CONFIGURATION</u>	<u>QUANTITY</u> <u>REQUIRED</u>	<u>PART</u> <u>DESCRIPTION</u>	<u>CONAIR GATTO</u> <u>PART NO.</u>
--	------------------------------------	-----------------------------------	--

(Recommended replacement parts for the Upper Traverse Assy.)

R/L	1	Prod. Guide Roller Assy.	0814-05798
R-L	1	Pusher Assy.	0814-05992
L-R	1	Pusher Assy.	0814-06018
R/L	3	Bearings, Jilson	3558-01126
R-L	1	Vertical Roller Assy.	0814-05429
L-R	1	Vertical Roller Assy.	0814-05437
R/L	1	Vertical Roller Assy. #2	0814-05496
R/L	1	Spring, Lee	4542-01009

(Recommended replacement parts for the Detector Assembly)

R/L	1	Bearing, Jilson	3558-01169
-----	---	-----------------	------------

(Recommended spare parts for the Lower Traverse Assembly)

R/L	1	Air Cylinders, Festo	5503-02568
R/L	2	Bearings, Flange	3561-00319
R/L	1	Rodless Cylinder, Festo Repair Kit	5503-02576

CONAIR

MACHINERY DEVELOPMENT

<u>MACHINE CONFIGURATION</u>	<u>QUANTITY REQUIRED</u>	<u>PART DESCRIPTION</u>	<u>CONAIR GATTO PART NO.</u>
(Recommended spare parts, for Turret Assembly)			
R-L	1	Clutches, Horton	3552-00888
R-L	1	Bearing, Pillow Block	3507-00494
R-L	1	Chain Conn. Link #40	3525-00019
(Recommended spare parts for cutting tool assembly)			
R-L	1	Bearing, Oilite	3560-01664
R-L	1	Sleeve, Oilite	3560-01672
(Recommended spare parts for detent assembly)			
R-L	1	Detent	0814-08894
R-L	1	Ball Bearing	3558-01185
R-L	1	Bearing, Bronze	3560-01753
R-L	1	Switch, Actuator	0814-08843
R-L	1	Cylinder, 2x, Festo Repair Kit	5503-02584
R-L	1	Bearing, Bronze	3561-00343
(Recommended spare parts for the Shot Pin Assembly)			
R-L	1	Positioner, Arm Assy.	0814-09068
R-L	1	Bushing, Oilite	3560-00013
R-L	1	Positioners, Turret	0814-09033
R-L	1	Bearing, Rod End	3509-00122
R-L	1	Follower Cam, McGill	3501-00131
R-L	1	Air Cylinder, DSW, Festo Repair Kit	5557-00277

CONAIR

MACHINERY DEVELOPMENT

MACHINE CONFIGURATION	QUANTITY REQUIRED	PART DESCRIPTION	CONAIR GATTO PART NO.
-----------------------	-------------------	------------------	-----------------------

(Recommended spare parts for the Lower Traverse Assembly)

R/L	2	Ball Bearings, Boston	3558-00227
R/L	2	Bearings, McGill	3501-00069
R/L	1	Bearing, McGill	3501-00387
R/L	1	Belt, Timing	3512-01164
R/L	1	Torque Limiter, OSD	3576-00064
R/L	1	Chain Con. Link, #40	3525-00019
R/L	1	Belt, Timing	3512-01318
R/L	1	Belt, Timing	3512-00672
R/L	1	Belt, Timing	3512-00133

(Recommended spare parts for Collapsible Core Assys.)

* Parts based on customer experience with Gatto & Vulcan units

(Recommended spare parts for the ATC Frame Assy.)

R-L	1	Stud, Leveling	0814-08614
R-L	1	Fastener, Southco	4504-00384
R-L	6	Clips, Panel	0814-07871

(Recommended spare parts for Turret Assembly)

R-L	1	Bearings, Flange	3505-00691
R-L	2	Ball Bearings, MRC	3558-00049
R-L	1	Bearings, Flange	3505-00187
R-L	1	Bearings, Flange	3505-00098
R-L	2	Wheel Guides	3556-00262
R-L	2	Adapters, Bushing	3556-00289

CONAIR

MACHINERY DEVELOPMENT

<u>MACHINE CONFIGURATION</u>	<u>QUANTITY REQUIRED</u>	<u>PART DESCRIPTION</u>	<u>CONAIR PART NO.</u>
		(Recommended spare parts for miscellaneous)	
R/L	1	Actuator, Turrent Sensor	0814-09246

CONAIRMACHINERY DEVELOPMENT

MACHINE CONFIGURATION	QUANTITY REQUIRED	PART DESCRIPTION	CONAIR PART NO.
8.1 <u>SPARE PARTS - ELECTRICAL</u>			
(Recommended spare parts for motor control system)			
R-L	1	Motor Control	1531-01431
(Recommended spare parts for programmable control system)			
R-L	1	EE Prom, A.B.	1590-00279
(Recommended spare parts for sensors and components)			
R-L	1	Footage Counter, (present)	1540-00634
R-L	2	Proximity Detectors	1616-00108
R-L	1	Mercury Switch	1627-00029
R-L	1	Limit Switch	1613-00603
R-L	1	Ultrasonic Loop Control	0814-08851
R-L	1	Encoder	1545-00527
R-L	1	Power Supply 24 VDC	1650-00133
R-L	1	Pressure Sensor	1615-00066
R-L	1	Fuse	1552-02039
R-L	1	Relay Interface	1601-01019
R-L	1	Transistor	1608-00727
R-L	1	Relay	1601-00241
R-L	1	Photo Detector	1583-00255

CONAIR

MACHINERY DEVELOPMENT





MACHINE CONFIGURATION	QUANTITY REQUIRED	PART DESCRIPTION	CONAIR GATTO PART NO.
-----------------------	-------------------	------------------	-----------------------

8.1 SPARE PARTS - PNEUMATIC

(Recommended spare parts for the Shot Pin Assembly)

R-L	1	Flow Control, Festo	5557-00188
R-L	1	Flow Control, Festo	5557-00234
R-L	1	Flow Control, Festo	5557-00285
R-L	1	Valve, Solenoid	5557-00285
R-L	1	Valve, Solenoid	5557-00099
R-L	1	Regulator/Filter Gauge	5501-00363
R-L	1	Regulator	5501-00355
R-L	1	Switch, Limit, Festo	5557-00536
R-L	1	Switch, Micro, Festo	5557-00196
R-L	1	Push-button, Festo	5557-00587
R-L	1	Valve, Pilot	5557-00153
R-L	1	Union, Rotating	5526-00139
R-L	1	Tubing Section (10')	5557-00374
R-L	1	Tubing Section (10')	5557-00382


REV	DESCRIPTION	DATE BY	APP
A	POSITION CONTROL AND IN REPAIR KIT	2/17/99	RJC



DRAWING	ITEM	PART NO.	QTY.	MATERIAL	DESCRIPTION
17	2539-00023		1		KNOB
16	1542-00682		1		TOP LIMIT ASS'Y
15	1625-00668		6		TEST POINT
14	1619-00818		1		SWITCH
13	1585-00074		1		POT
12	1585-00287		1		POT
11	1543-00015		1		DIAL
10	1586-00035		1		POT
9	1622-00039		1		SWITCH
8	0814-12247		1		BRACKET
7	1531-01253		1		PID ASSY.
6	1542-00666		1		SUMMING CKT.
5	1542-00658		1		MULTIPLIER
4	1542-00631		1		F TO V CONV.
3	1650-00214		1		POWER SUPPLY
2	1542-00674		1		ULTRASONIC DET.
1	SUPPLIED		1		PANEL


NOTES: 1. ASSEMBLE FROM ALL PARTS LISTED 2. USE SPECIFIED MATERIALS 3. SEE DIMENSIONS FOR LOCATION 4. SEE DIMENSIONS FOR SCALE 5. SEE DIMENSIONS FOR TOLERANCES	REVISIONS BY: DATE: REVISED BY: DATE: REVISED BY: DATE:
--	--

GATTO MACHINERY DEVELOPMENT CORP	
11/20/05	11/20/05
GATTO MACHINERY DEVELOPMENT CORP	
TITLE: LOOP CONTROL LAYOUT	
DRAWING NO.: X559-1071	



DRAWING NUMBER		SYM		QTY		PART NUMBER		DESCRIPTION	
0814-30048		1	1			2504-02732		HOFFMAN BOX A42H3010SSLP	
NOTES:		TOLERANCE UNLESS OTHERWISE NOTED.		<p style="text-align: center;">CONAIR</p> <p style="text-align: center;">GATTO MACHINERY DEVELOPMENT CORP.</p> <p style="text-align: center;">TITLE COILER EQ. BOX LAYOUT R-L MACH.</p>					
EXCEPT AS NOTED FINISH		XX = ± 0.010							
ALL OVER TO ✓		XXX = ± 0.005							
BREAK ALL CORNERS UNLESS OTHERWISE NOTED		ANGLES ± 1/2°							
DO NOT SCALE PRINT.		ALL INFORMATION CONTAINED IN OR DISCLOSED BY THIS DOCUMENT IS CONFIDENTIAL. ALL DESIGN MANUFACTURE USE REPRODUCTION AND SALES RIGHTS ARE RESERVED BY CONAIR / JETRO.		DRAWN BY J.M.		DATE 04/18/94		PART NUMBER 0814-30048	
CHECKED BY		SCALE 1/4		REV D		REV		REV	

FRONT



58	1	1635-01565	TRANSFORMER 241-6-28
57	1	0202-06507	FLYWHEEL SPD INTERFACE MTG BRACKET
56	1	1607-01037	RESISTOR 18K OHMS
55	1	1607-00995	RESISTOR 1,000 OHMS
54	4	1608-00387	DIODE DT3 1N4148
53	1	1518-00612	SPRAGE 1MF CAP. 15VDC
52	1	1608-00727	TRANSISTOR 2N4400 NPN
51	1	1595-00218	GE DIODE 1N5060
50	1	1608-00778	ZENER DIODE ECG5126A
49	20'	2507-00072	1x2 WIRE CHANNEL COVER
48	1	1590-00279	AB EE-PROM 1745-M1
47	20'	2507-00013	1x2 WIRE CHANNEL
46	4	1505-00052	END SECTION BUCH-630
45	97	1505-00044	TERM BLOCK BUCH-625
44	1	1542-00704	WADDINGTON MOUNTING TRACK
43	1	1542-00666	WADDINGTON SUMMING SUM-3
42	1	1542-00658	WADDINGTON MULTIPLIER MUX-2
41	1	1542-00631	WADDINGTON F/V CONVERTER F/V-1
40	1	1650-00214	WADDINGTON POWER SUPPLY PS-3
39	1	1531-01253	REFLEX MOD204 PID ASSY.
38	1	1531-01431	RELIANCE 2HP DC REGEN DRIVE 14C10B
37	1	1542-00682	LBI TOP LIMIT SENSOR
36	9	1608-00018	GE VARISTOR V130LA2
35	2	1588-00407	KEYSTONE PC BOARD 15032
34	1	1607-01541	RESISTOR 1,500 OHMS
33	1	1607-00219	RESISTOR 100K OHMS
32	2	1607-00553	RESISTOR 100 OHMS
31	1	1607-00804	RESISTOR 1,800 OHMS
30	1	0814-12247	POSITION CONTROL BRACKET
29	9	1625-00668	KULKA SMITH JACK 1507-103
28	1	2539-00023	ALCO KNOB
27	1	1619-00818	SEL. SWITCH 22F837
26	1	1585-00074	CLAROSTAT 5K POT.
25	1	1585-00287	CLAROSTAT 2K POT.
24	1	1543-00015	BECK DIAL RB-15DU0
23	1	1586-00035	BECK 5K POT. AR5KL25
22	1	1622-00039	TOGGLE SWITCH
21	1	1542-00674	SONA-TROL SPEED CONTROL
20	1	1590-00252	AB PROC. EXPANSION UNIT 1745-E153
19	1	1650-00133	TAMUPA POWER SUPPLY OLS24N
18	1	1647-00394	P&B 11-PIN SOCKET
17	1	1601-00241	P&B RELAY KRPA-14AN-120
16	1	1601-01019	DYNAPAR RELAY PM-31
15	1	1590-00325	AB HIGH SPEED COUNTER 1745-E155
14	1	1590-00244	AB PROC. SLC-150 1745-LP151
13	1	0814-13294	GROUND BUSS
12	1	1611-00096	AB DISCONNECT SWITCH 1494R-N30
11	3	1563-00216	AB OL HEATER W-44
10	1	1609-00224	AB STARTER 509-TOD
9	1	1552-02039	FUSE FNQ-5
8	1	1503-00063	ACME FUSE BLOCK 112601
7	1	1634-00077	ACME TRANSFORMER 350VA
6	4	1552-02004	FUSE FRN-25
5	1	1611-00134	AB DIS. SWITCH SHAFT KIT 1494R-N4
4	1	1502-00361	AB FUSE BLOCK 1491-N122
3	1	1502-00078	BUSS FUSE BLOCK BM603-25Q
2	2	1552-01962	FUSE FNQ-3 2/10
1	1	A-42P30	HOFFMAN PANEL A-42P30

DRAWING NUMBER
0814-30056

NOTES:
TOLERANCE UNLESS OTHERWISE NOTED.
EXCEPT AS NOTED FINISH
ALL OVER TO
BREAK ALL CORNERS UNLESS OTHERWISE NOTED.
DO NOT SCALE PRINT.

CHECKED BY: _____
DATE: 04/18/94
SCALE: 1/2"


CONAIR
GATTO MACHINERY DEVELOPMENT CORP.
TITLE: COILER EQ. PANEL LAYOUT W/MAX-2

SYMBOL QTY PART NUMBER DESCRIPTION

DRAWN BY: _____
DATE: 04/18/94
SCALE: 1/2"

SHEET 1 OF 1

0814-30056




DRAWING NUMBER 0814-30064		SYMBOL		QTY		PART NUMBER		DESCRIPTION	
NOTES: EXCEPT AS NOTED FINISH ALL OVER TO BREAK ALL CORNERS UNLESS OTHERWISE NOTED. DO NOT SCALE PRINT.		TOLERANCE UNLESS OTHERWISE NOTED. XX = ± 0.010 .XXX = ± 0.005 ANGLES ± 1/2°		DRAWN BY DATE 04/18/94		PART NUMBER D 0814-30064		REV	
CHECKED BY		ALL INFORMATION CONTAINED IN OR DISCLOSED BY THIS DOCUMENT IS CONFIDENTIAL. ALL DESIGN MANUFACTURE USE REPRODUCTION AND SALES RIGHTS ARE RESERVED BY CONAIR / JETRO.		SCALE NONE		TITLE COILER 460V W/MAX COUNT-2		REV	

B	LOCATED TRANS. BEFORE DISCONT. SWITCH.	SJB	01/20/97
A	SWAP MIN AND MAX POT.	DH	12-13-95
SYM.	REVISION	BY	DATE

File Name: WFF006E.DWG Plotted 07-13-94 12:36

A	CHANGE 10K TO 2.0K	RL	01/95
SYM.	REVISION	BY	DATE



65	2	1607-00553	RESISTOR 100 OHMS				
64	1	1607-01541	RESISTOR 1.5K OHMS				
63	1	1564-00074	MALLORY SONALERT HORN 30-120V				
62	1	1607-00219	RESISTOR 100K OHMS				
61	1	1632-00134	REDINGTON TIMER 711-00107 120VAC				
60	1	1519-00047	AB PILOT LIGHT CAP N42 (AMBER)				
59	1	1540-00499	DYNAPAR MAXy TACH-1				
58	1	1647-00394	P&B 11-PIN SOCKET				
57	1	1615-00066	BARKSDALE PRESSURE SWITCH D1H-AB0				
56	3	1519-00012	AB PILOT LIGHT CAP N40 (RED)				
55	1	1564-00015	EDWARDS HORN B74-N5				
54	1	1584-00208	EDWARDS BEACON-RED47R-N5				
53	1	1650-00133	TAMURA POWER SUPPLY QLS24N				
52	1	1622-00039	TOGGLE SWITCH 110-S-73				
51	1	1542-00674	SONA-TROL SPEED CONTROL				
50	5	1616-00108	TURCK PROX. SWITCH BI5-G18-AP6X				
49	1	1590-00252	AB PROG. EXPANSION UNIT 1745-E153				
48	3	5557-00099	FESTO-SINGLE SOL. VALVE 10836MFH				
47	3	5557-00102	FESTO-SINGLE SOL. VALVE 9765 MFH				
46	1	1609-00224	AB STARTER 509T00				
45	2	1583-00255	PHOTO SWITCH 42 LRC-5010				
44	1	1613-00603	MICRO LIMIT SWITCH BZE6-2RQ2				
43	1	1627-00029	DURAKOOL MERCURY SWITCH A1-002				
42	1	1593-00245	AB PUSH BUTTON CONTACT 800T-XA				
41	1	1593-00148	AB PUSH BUTTON 800T-B602				
40	1	1590-00244	AB PROG. SLC-150 1745-LP151				
39	1	1607-01037	RESISTOR 18K OHMS				
38	1	1607-00995	RESISTOR 1K OHMS				
37	1	1608-00727	TRANSISTOR 2N4400 NPN				
36	1	1619-00818	SEL. SWITCH 22F837				
35	1	1593-00091	AB PUSH BUTTON 800T-A9D1				
34	5	1608-00387	DIODE DT3 1N4148				
33	1	1540-00774	DYNAPAR MAX COUNT-2				
32	1	1593-00059	AB PUSH BUTTON 800T-A1D1				
31	1	1540-00669	DYNAPAR MAXy COUNT -1				
30	1	1650-00214	WADDINGTON POWER SUPPLY PS-3				
29	1	1542-00631	WADDINGTON F/V CONVERTER F/V-1				
28	1	1542-00658	WADDINGTON MULTIPLEXER MUX-2				
27	1	1542-00666	WADDINGTON SUMMING SUM-3	91	1	2539-00023	ALCO KNOB
26	1	1608-00778	ZENER DIODE ECG5126A	90	1	1590-00279	AB EE-PROM 1745-M1
25	1	1595-00218	GE RECTIFIER DIODE 1N5060	89	1	1531-01253	REFLEX MOD204 PID ASSY.
24	1	1601-00241	P&B RELAY KRPA-14AN-120	88	1	1607-00502	RESISTOR 2.0K OHMS
23	1	1519-00063	AB PILOT LIGHT CAP N44 (WHITE)	87	1	1590-00325	AB HIGH SPEED COUNTER 1745-E155
22	1	1594-00036	AB PILOT LIGHT 800T-PA16	86	1	1593-01446	SQ-D PUSH BUTTON XAL-B164
21	1	1593-00679	AB PUSH BUTTON 800T-D6D2	85	1	1635-00348	ACME TR. 5 KVA TF-2-52520-S 415V
20	1	1519-00136	AB PILOT LIGHT CAP N26W (WHITE)	85	1	1635-00119	ACME TR. 5 KVA T-2-53014-4S 460V
19	5	1584-00178	AB PILOT LIGHT 800T-PT16	84	1	1607-00502	RESISTOR 2K OHMS
18	1	1552-02039	FUSE FNQ-5	83	15'	1517-00015	10-3 SO CORD
17	1	1503-00063	ACME FUSE BLOCK 112601	82	1	1601-01019	DYNAPAR RELAY PM-31
16	9	1608-00018	GE VARISTOR V130LA2	81	1	1585-00287	CLAROSTAT 2K POT.
15	1	1613-00603	MICRO LIMIT SWITCH BZE6-2RQ2	80	1	1586-00035	BECK POT. AR5KL25
14	2	1552-01962	FUSE FNQ-3 2/10	79	1	1585-00074	POT. 1 TURN JAILO40S502U
13	1	1502-00078	BUSS FUSE BLOCK BM603-2SQ	78	1	1645-01172	AMPHENOL CONNECTOR 3102A 18-9
12	1	1634-00077	ACME TRANSFORMER 350VA	77	1	1644-00938	AMPHENOL PLUG 3106A 18-9P
11	2	1543-00015	BECK DIAL RB-15DUQ	76	1	1646-00587	CANNON RECEPTACLE AXR-4-31
10	1	1586-00035	BECK 5K POT. AR5KL25	75	1	1644-00555	CANNON PLUG AXR-4-12R
9	2	1593-00067	AB PUSH BUTTON 800T-A201	74	1	1545-00527	ENCODER ENC711
8	1	1579-01042	RELIANCE DC 2HP MT56H1058 MOTOR	73	1	1635-01573	SIGNAL TRANSFORMER 241-6-12
7	1	1531-01431	RELIANCE 2HP DC REGEN DRIVE 14C108	72	2	1635-01565	SIGNAL TRANSFORMER 241-6-28
6	1	1577-01215	RELIANCE AC 1/2HP 115/230V MOTOR	71	1	1542-00682	LBI TOP LIMIT SENSOR
5	3	1563-00216	AB O.L. HEATER W-44	70	1	1607-00804	RESISTOR 1.8K OHMS
4	4	1552-02004	FUSE FRN-25	69	1	1518-00612	SPRAGE 1MF0 CAP 15VDC
3	2	1502-00361	AB FUSE BLOCK 1491-N122	68	1	1593-01179	AB PUSH BUTTON 800T-PB16
2	1	1611-00096	AB DISCONNECT SWITCH 1494R-N30	67	1	1584-00127	AB PILOT LIGHT 800T-P16
1	1	1644-00067	HUBBELL PLUG	66	1	1519-00055	AB PILOT LIGHT CAP N43 (BLUE)

0814-30064

NOTES: EXCEPT AS NOTED FINISH ALL OVER TO BREAK ALL CORNERS UNLESS OTHERWISE NOTED DO NOT SCALE PRINT.


TOLERANCE UNLESS OTHERWISE NOTED: XX = ± 0.010 XXX = ± 0.005 ANGLES = 1/2°

CONAIR
GATTO MACHINERY DEVELOPMENT CORP.
TITLE: COILER 460V W/MAX COUNT-2

CHECKED BY: [Signature] ALL INFORMATION CONTAINED IN OR DISCLOSED BY THIS DOCUMENT IS CONFIDENTIAL. ALL DESIGN MANUFACTURE USE REPRODUCTION AND SALES RIGHTS ARE RESERVED BY CONAIR / JETRO.

DRAWN BY: [Signature] DATE: 04/18/94 PART NUMBER: [Blank] REV: [Blank]

SCALE: NONE D PART NUMBER: 0814-30064 REV: A




SEQUENCE OF OPERATION
 START POSITION
 SPINDLE "A" RUNNING
 SPINDLE "B" SET-UP READY FOR AUTO TURRET
 CUTTER "A" RETRACTED
 CUTTER "A" POWER VALVE IN POSITION -A
 DETENT "A" RETRACTED
 DETENT "A" POWER VALVE IN POSITION -A
 SPINDLE "A" CLUTCH ENGAGED
 SPINDLE "A" BRAKE DISENGAGED
 SPINDLE "A" CLUTCH/BRAKE POWR. VALVE IN POS. -B
 SPINDLE "A" TURRET SENSOR UNACTUATED NC
 SPINDLE "A" DETENT SENSOR UNACTUATED NC
 SPINDLE "A" CUTTER RETRACTOR SENSOR UNACT. NC
 SPINDLE "A" CUTTER FORWARD SENSOR UNACT. NO
 CUTTER "B" EXTENDED
 CUTTER "B" POWER VALVE IN POS. -B
 DETENT "B" EXTENDED
 DETENT "B" POWER VALVE IN POS. -B
 SPINDLE "B" CLUTCH DISENGAGED
 SPINDLE "B" BRAKE DISENGAGED
 SPINDLE "B" CLUTCH/BRAKE POWER VAL. IN POS. -A
 SPINDLE "B" TURRET SENSOR UNACTUATED NC
 SPINDLE "B" DETENT SENSOR ACTUATED OPEN
 SPINDLE "B" CUTTER RETRACT SENSOR UNACT. NC
 SPINDLE "B" CUTTER FORWARD SENSOR ACT. CLOSED
 TRAVERSE SOLENOID VALVE UNACTUATED NO
 TRAVERSE CYLINDER IS RETRACTED
 TRAVERSE CLAMPS CYL. SOLENOID VALVE ALTERNATELY ACTUATED NC
 LAY-ON ARM CYLINDER IS EXTENDED
 LAY-ON ARM SOL. VAL. UNACTUATED NO (POS-B)

WHEN SPOOL IS FULL UNIT TURRETS
 LAY-ON ARM SOL. VAL. ENGAGES
 LAY-ON ARM LIFTS
 TRAVERSE SOL. VAL. ACTUATED (POS. A)
 TRAVERSE CYL. EXTENDED & TRAVERSE CLAMPS CYL. RETRACTED
 LAY-ON ARM SOL. VALVE DIENERGIZES (POS. B)
 LAY-ON ARM DROPS PRIOR TO TRAVERSE ENGAGING
 JUST BEFORE STOPPING SPINDLE "B" TURRET SENSOR IS ACTUATED (OPENED) MOMENTARILY THIS SHIFTS DETENT "B" POWER VALVE FROM POS B TO POS A RETRACTION DETENT B UPON RETRACTION DETENT "B" SENSOR DEACTUATES (CLOSES) EXHAUSTING PILOT SIGNAL TO CUTTER "B" POWER VALVE ALLOWING IT TO SHIFT TO POSITION A WHICH RETRACTS THE CUTTER
 CUTTER "B" RETRACTED SENSOR IS ACTUATED (OPENED MOMENTARILY)
 THIS SHIFTS CLUTCH/BRAKE POWER VALVE "B" TO POS. A WHICH DISENGAGES BRAKE AND ENGAGES CLUTCH
 CLUTCH/BRAKE POWER VALVE "A" SHIFTS TO POSITION "B" DISENGAGING CLUTCH "A" AND ENGAGING BRAKE "A" MOMENTARILY OPERATOR REMOVES REEL AND PUSHES CUTTER "A" EXTEND PUSHBUTTON AND ROTATES SPINDLE UNTIL DETENT ENGAGES
 PUSHBUTTON VALVE SHIFTS DETENT "A" POWER VALVE TO POSITION B
 DETENT ENGAGED SENSOR ACTUATES (OPENS) SHIFTING CUTTER "A" POWER VALVE TO POS. B. CUTTER "A" EXTENDS ACTUATING FORWARD SENSOR

NOTE: NUMBERS IN () CORRESPOND TO MACHINE TUBING IDENTIFICATION NUMBERS

DRAWING NUMBER X559-886		SYM QTY PART NUMBER DESCRIPTION	
NOTES: EXCEPT AS NOTED FINISH ALL OVER TO BREAK ALL CORNERS UNLESS OTHERWISE NOTED. DO NOT SCALE PRINT.		TOLERANCE UNLESS OTHERWISE NOTED. .XX = ± 0.010 .XXX = ± 0.005 ANGLES ± 1/2°	
DRAWN BY DATE M. BURK 01-20-97		PART NUMBER 0814-09122	
CHECKED BY M. BURK		REV	
SHEET 1 OF 1		REV	

REV.	DESCRIPTION	DATE	BY	APP.
A	ADDED ITEM # 37 (SEE 25 & 34)	10/18/88	D	AH
B	UPDATED TO REFLECT 'AS BUILT'	2/1/89	D	AH
C	ADDED ITEMS # 39, 40, 41	10/18/87	MP	



DRAWING	ITEM	PART No.	QTY.	MATERIAL	DESCRIPTION
	41	4509-00544	1	SS-NX-NUT	1/4-20
	40	4538-01908	1	SS-NA-HD.SCR.	1/4-20 X 1 1/8 LG
AX559-1115	39	0814-12492	1	SS-NEW NUT	2X1/8 AMT GEAR CABLE
	38	4509-00258	1	SS-NEW NUT	3/8-16
	37	4536-08192	2	SCND-CAP.SCR.	SS #10-32 X 3/4 LG
	36	4536-02095	3	SCND-CAP.SCR.	SS #10-32 X 1 1/8 LG
AX559-654	35	0814-05585	1		SENSOR MTE. BRKT.
AX559-653	34	0814-05577	1		SENSOR MTE. BRKT.
	33	4534-00419	4	FLND SC-SCRWB	1/4-20 X 1 1/8 LG
AX559-655	32	0814-05593	1		CLAMP
	31	4542-01009	1	SPRING, LEE	ST.SF. # LE-0188-7
AX559-665	30	0814-05755	2		BR. MODIF.
	29	3562-00043	2	THRUST-WASHER	BOSTON # 1816, # 9/8
AX559-1095	28	0814-12182	1		SHOULDER RBA, MODIFIED
CX559-790	27	0814-07669	1		1/8" ROLLER
BX559-687	26	0814-06069	1		IDLER ROLLER - ASSY
	25	4536-01676	5	SCND-CAP.SCR.	SS 1/4-20 X 1 1/2 LG.
AX559-664	24	0814-05785 (REL)	1		DETECTOR ASSY
BX559-658	23	0814-05337 (REL)	1		MTE. PLATE - WELD
	22	4527-00497	5	SEPSCR, SS	1/4-20 X 1/2
	21	4527-00829	1	SEPSCR, SS	#10-32 X 3/8 LG
	20	4516-00924	1	RET. RING	# 5700-B7 - WALDES
AX559-652	19	0814-05569	1		SHAFT
AX559-650	18	0814-05534	1		SLEEVE
	17	4518-00611	3	ROLL-PIN, SS	3/32 X 3/4 LG.
CX559-647	16	0814-05496	1		VERT. ROLLER ASSY #2
CX559-642	15	0814-05433 (REL)	1		VERT. ROLLER ASSY #1
AX559-670	14	0814-05836	1		STOP
	13	4516-00746	3	RET. RING	WALDES # 5700-46
AX559-692	12	0814-06115	1		ROLLER SHAFT
CX559-668	11	0814-05798	1		PR. GUIDE ROLLER - ASSY
CX559-663	10	0814-05388 (REL)	1		PUSHER - ASSY
CX559-691	9	0814-06107	1		PR. GUIDE - ASSY
AX559-704	8	0814-06899	4		SPACER
	7	4536-02435	1	SCND-CAP.SCR.	ST.ST. 3/8-16 X 1 1/8 LG.
AX559-677	6	0814-05925	1		BLOCK
	5	4536-00262	2	SCND-CAP.SCR.	ST.ST. 1/4-20 X 1 1/8 LG.
CX559-674	4	0814-05895	1		SIDE PLATE #1
CX559-675	3	0814-05909	1		SIDE PLATE #2
	2	4534-00362	8	FLND.SCR.SCR.	ST.ST. 1/4-20 X 1 1/8 LG.
CX559-669	1	0814-05820 (REL)	1		BASE PLATE (UPPER TR.)

TOLERANCE UNLESS OTHERWISE NOTED
 FINISHES: 7 (SEE 25 & 34)
 DIMENSIONS: 1/8" (SEE 25 & 34)
 UNLESS OTHERWISE NOTED
 DO NOT SCALE
 PRINT

GATTO MACHINERY DEVELOPMENT CORP.
 DATE: 2/16/88
 DRAWN BY: [Signature]
 DATE: 2/16/88
 TITLE: UPPER TRAVERSE - ASSY
 SCALE: FULL
 D X559-693

(L-R) - OPPOSITE
(R-L) - OPPOSITE

6 1/4 REF.

6 1/8 REF.

4/8 REF.

0814-06107 (L-R)